


DFB Quantum Cascade Lasers in the 10.7 µm region

description

nanoplus 10.7 μ m DFB quantum cascade lasers show unique device performance to meet the requirements of our customers. Their high side mode supression ratio (SMSR) and high spectral purity make them perfectly suited for applications like e.g. NH $_3$ sensing. The devices work in pulsed mode at operation temperatures up to 270 K.



specifications *

') preliminary data

Parameter	Symbol	Unit	min	typical	max
Wavelength		μm		10.80	
Optical output power	P _{opt}	mW	1	3	5
Forward current	I _f	Α	4.5	6	6.5
Threshold current	I _{th}	А	5	5.5	6
Beam divergence parallel		deg.	35	40	45
Beam divergence perpendicular		deg.	55	60	65
Emitting area	WxH	μm		8x20	
Slope efficiency	е	mW/A	1.5	2	2.5
Temperature tuning rate	C_{T}	nm/K	0.4	0.5	0.6
Pulswidth	Dt	ns		100	150
Rep. Rate	.f	kHz		.3	10

nanoplus GmbH Nanosystems and Technologies Oberer Kirschberg 4 D-97218 Gerbrunn Germany phone: +49 931 90827-0 fax: +49 931 90827-19

www.nanoplus.com sales@nanoplus.com

© Copyright nanoplus GmbH 2004. All rights reserved. nanoplus GmbH reserves the right to modify these specifications at anytime without notice



absolute maximum ratings

Parameter	Symbol	Unit	Rating
LD forward current	l _f	Α	7
Operating temperature	T _{op}	K	<260
Storage temperature	T _{store}	K	0 to 370

applications

trace gas sensing of NH₃

packaging

nanoplus offers a wide variety of different packaging options for their FP and DFB laser diodes in the entire wavelength range, including C-mount or TO 8 header with or without Peltier cooler. Please refer to our *packaging datasheet* for more information.

Other customized packages (e.g. mounting on customer specific submounts) are available upon request. Please do not hesitate to contact us for further details.



nanoplus GmbH Nanosystems and Technologies Oberer Kirschberg 4 D-97218 Gerbrunn Germany phone: +49 931 90827-0 fax: +49 931 90827-19

sales@nanoplus.com

www.nanoplus.com