


## **EPS1000** Polarization Scrambler/Transformer

- Ultrafast endless optical polarization scrambling with 40 ns updating intervals
- Continuous, quasi-steady endless polarization trajectories 0.01 rad/s ... 10000 krad/s (20000 krad/s with reduced accuracy). Small steps, e.g., 0.02 rad at 500 krad/s
- 6 electrooptic quarterwave plates (QWP) and 1 halfwave plate (HWP) with adjustable rotation speeds (QWP: -999999.99 ... +999999.99 rad/s; HWP: -10000.00 ... +10000.00 krad/s)
- Optical frequency can be preset for most accurate waveplate operation, at least from C band to L band (186.2 ... 196.0 THz, 1529 ... 1610 nm). Optional: S band, 1310 nm
- Insertion loss ~1.5 ... 3 dB. Power consumption ~12 W (+5 V power supply 100 ... 240 V included)
- Differential group delay (DGD) sections consisting of polarization-maintaining fibers (PMF) available for highly realistic PMD emulation, using several EPS1000 and DGD sections.
- Available as a desktop unit, module or intellectual property core
- Operation of desktop unit via control buttons or USB (software is included). Several units can be controlled simultaneously by the graphical user interface (see p. 2) or by Matlab<sup>™</sup>. Speeds of rotating and positions of stopped waveplates and electrode voltages can be set, saved and loaded.
- Serial Peripheral Interface (SPI) for realtime operation; e.g., direct setting of waveplate voltages.
- In synchronous scrambling mode, user-generated tables with sets of waveplate positions can be loaded. Following an external trigger event (3.3 V LVCMOS signal applied at BNC connector, or SPI command) the sets are executed sequentially at specified instants (granularity: 40 ns; minimum delay until next execution instant: 200 ns). Useful for recirculating loop experiments.
- In triggered scrambling mode, the sets are executed cyclically one by one upon external trigger events or USB commands (minimum delay until next execution instant: 200 ns). Application examples: polarization-dependent loss (PDL) and Mueller/Jones matrix measurements.
- Optional photodetectors enable accurate PDL and loss measurements
- EPX1000 = cost-saving desktop unit with combined functionalities of EPS1000 and 40...100 krad/s
  polarization controller/demultiplexer EPC1000
- PMS1000 = combination of EPS1000 with ultrafast (100 MHz) polarimeter PM1000





HWP operation Fast HWP operation Exemplary output trajectories on Poincaré sphere



Electrical scrambling spectrum behind polarizer at 10 Mrad/s (horizontal: Hz; vertical: 10 dB/div)



60-V step at HWP settles completely within 50 ns (20 ns/div). Small-signal response is a lot faster.





FPGA-based

electronic controller

LiNbO<sub>2</sub>

Band

HWP:

HWP Sweep: Min: 0

2 3

3

1

1 2

Novoptel EP51000 User Interface

optical

output

.

QWP1: 123456,00 rad/s (123456,00 rad/s) Set

QWP2: 214365,87 rad/s (214365,87 rad/s) Set

QW/P3 876543,21 rad/s (876543,21 rad/s)

QWP4: 784523,12 rad/s (784523,12 rad/s) Set

4 5

4 5

optional tap

Rotation Control | Position Control | Voltage Control | Synchronous/Triggered Scrambling | Device Testing |

Optical Frequency: 193.2 THz (193,2 THz 1551,7 nm)

Set

All Wave Plates: Backward

7

6

krad/s Delay: 1

8

Backward

coupler

Select Device: EPS1000-10M-XL-LL-N-D DEM0 V Status: Connected

QWP0: 9999999,99 rad/s (999999,99 rad/s) Set Backward

QWP5: 432109,87 rad/s (432109,87 rad/s) Set Backward

20000,00 krad/s (20000.00 krad/s) Set Backward

Max 1000 Step: 10

optical

Novoptel

Load Configuration:

Save Configuration:

EPS1000+1:

input

All rights reserved

optical power measurement

Stop

Stop

Stop

Stop

Stop

Stop

Stop

Stop

9 10

Set

Forward

Forward


Forward

Forward

Start

Import

Export




Optomechanical switch available for device-under-test switching.

Shown are frequently used operation modes of USB-operated graphical user interface.

Other operation modes are:

- Voltage Control: Direct setting of 16 electrode voltages
- Device Testing: Intensity recording for PDL and loss measurement (optional)



Novoptel GmbH EIM-E Warburger Str. 100 33098 Paderborn Germany Tel. +49 5251 60 2245 Fax +49 5251 60 5827

www.novoptel.com info@novoptel.com



## **N**ovoptel