

## **Radar Target Simulator, Level Setting**

### **Description:**

Model STR-243-42-L1 is a radar doppler simulator that operates from 18 to 26.5 GHz with a WR-42 waveguide input/output. The simulator utilizes a single-sideband-modulator to modulate the incoming signal transmitted by the radar under test and sends back either a higher or lower band signal through a diplexer. The frequency-shifted signal is transmitted back to the radar under test as a Doppler signal.



Target characteristics can be adjusted by changing the I and Q channel frequency and phase. The routing attenuation is adjusted by the level setting attenuator which can be calibrated to simulate the radar cross section (RCS).

#### **Features:**

- Single Sideband Output
- Simulated Target Speed and Size Adjustable
- Simulated Target Moving Direction Switchable
- Instrumentation Grade

### **Applications:**

- Doppler Target Simulations
- Radar Systems

## **Electrical Specifications:**

Parameter	Minimum	Typical	Maximum
Operating Frequency	18 GHz		26.5 GHz
Carrier Rejection		25 dB	
Image Rejection		20 dB	1 5
Routing Loss Range	. //	14 to 70 dB	
I/Q Frequency Range	DC		8.5 GHz
I/Q Voltage			±10 V <sub>p-p</sub>
I/Q Current		±2.5 mA	±5 mA
I/Q Phase Error		±5°	
Specification Temperature	VIIIIim	+25 °C	no
Operating Temperature	+0 °C	otol,	+50 °C

# **Mechanical Specifications:**


Item	Specification	
RF Port	WR-42 Waveguide with UG-595/U Flange	
I/Q Ports	SMA(F)	
Finish	Black Anodized	
Size	4.89" (W) x 9.06" (L) x 1.90" (H)	
Outline	TR-KL-2	



www.eravant.com | 501 Amapola Avenue, Torrance, CA 90501 Phone: 424-757-0168 | Fax: 424-757-0188 | Email: support@eravant.com



Mechanical Outline: (Unless otherwise specified, all dimensions are in inches [millimeters])



#### Note:

- A Radar Target Simulator with a direct reading attenuator, instead of a level setting attenuator, is available as model STR-243-42-D1.
- Eravant reserves the right to change the information presented without notice.
- Models with different operation frequencies are available under different model numbers.

#### **Caution:**

- Exceeding absolute maximum ratings will damage the device.
- Any foreign objects in the waveguide will cause performance degradation and may damage the device.
- Proper torque, 8.0 ± 0.15 inch-pounds (0.92 ± 0.02 Nm), should be applied. Eravant torque wrench, model <u>SCH-08008-S1</u>, is highly recommended.



www.eravant.com | 501 Amapola Avenue, Torrance, CA 90501 Phone: 424-757-0168 | Fax: 424-757-0188 | Email: support@eravant.com